


AIRTECT

Plastic Leak Alarm System



PRODUCTS AND ACCESSORIES CATALOGUE



‘FOCUS ON PREVENTION’

IMM 'NOZZLE' LEAK DETECTION MODULES

Page 2

LA501
LA502
LM2050Page 2
Page 2
Page 2**'STANDARD' HOT-RUNNER LEAK DETECTION MANIFOLDS**

Page 3

4-ZONELA504-X
LA504-M-H
LA504-M-SPage 4
Page 4
Page 4**8-ZONE**LA508-X-N
LA508-M-H-N
LA508-M-S-N
LA508-B-XPage 5
Page 5
Page 5
Page 5**16-ZONE**LA516-M-H-N
LA516-M-S-N
LA516-B-XPage 6
Page 6
Page 6**24-ZONE**LA524-M-H-N
LA524-M-S-N
LA524-B-XPage 7
Page 7
Page 7**'STAND-ALONE' HOT-RUNNER LEAK DETECTION MANIFOLDS**

Page 8

4-ZONELA504S-X
LA504S-M-H
LA504S-M-S
LA504-B-XPage 9
Page 9
Page 9
Page 9**8-ZONE**LA508S-X
LA508S-M-H
LA508S-M-S
LA508S-B-XPage 10
Page 10
Page 10
Page 10**16-ZONE**LA516S-M-H
LA516S-M-S
LA516-B-XPage 11
Page 11
Page 11**24-ZONE**LA524S-M-H
LA524S-M-S
LA524-B-XPage 12
Page 12
Page 12

'ULTIMATE' STAND ALONE HOT-RUNNER LEAK DETECTION MANIFOLDS

Page 13

6-POINT +1 LOOP

<u>LA506-1L-S-X</u>	Page 14
<u>LA506-1L-S-M-H</u>	Page 14
<u>LA506-1L-S-M-S</u>	Page 14
<u>LA508-B-X</u>	Page 14

12-POINT +2 LOOP

<u>LA512-2L-S-M-H</u>	Page 15
<u>LA512-2L-S-M-S</u>	Page 15
<u>LA516-B-X</u>	Page 15

20-POINT +2 LOOP

<u>LA520-2L-S-M-H</u>	Page 16
<u>LA520-2L-S-M-S</u>	Page 16
<u>LA524-B-X</u>	Page 16

ACCESSORIES

Page 17


<u>LA-MAN-2-X</u>	Page 17
<u>LA-MAN-4-X</u>	Page 17
<u>TUBE-SS-10M-X</u>	Page 17
<u>TUBE-PU-10M</u>	Page 17
<u>TUBE-SIL-10M-X</u>	Page 18
<u>NUT-SS-X</u>	Page 18
<u>FIT-SS-SS-X</u>	Page 18
<u>FIT-PU-SS-X</u>	Page 18
<u>BKT-SS</u>	Page 18
<u>NOZ-BKT</u>	Page 18
<u>PCC-X</u>	Page 19
<u>PCC-S-X</u>	Page 19
<u>AR-20GF</u>	Page 19
<u>IR-1000GF</u>	Page 19
<u>AR-G-5</u>	Page 19




NOZZLE AND BARREL PROTECTION

IMM 'NOZZLE' LEAK DETECTION MODULES

Work as IMM Nozzle Leak Detectors + Control/Display/Relay Interlock Modules for 'STANDARD' HOT-RUNNER Leak Detection Manifolds via a PCC-X Cable



LA501 SINGLE NOZZLE



LA502 DUAL NOZZLE

NOZZLE AND BARREL PROTECTION

IMM 'NOZZLE' LEAK DETECTION MODULES



LA501 'UNO' SINGLE INJECTION NOZZLE PLASTIC LEAK ALARM

Kit Includes:

- LA501 with 2 x 7-segment LED display with programmable operational settings
- ZR-20GF Air Pressure Regulator with Pressure Gauge, Air Filter and Fittings
- 3 Meters PU Tube
- 0.5 Metres 2mm Silicone Rubber Tube
- 3 Meters 2mm Stainless Steel Sensor Tube
- 2 x Nozzle Brackets with Stainless Steel Ties
- Installation/Operation Manual
- 2 Meter Electrical Power/Interlock Cable



LA502 'DUO' DUAL INJECTION NOZZLE PLASTIC LEAK ALARM

Kit Includes:

- LA502 with 2 x 7-segment LED display with programmable operational settings
- ZR-20GF Air Pressure Regulator with Pressure Gauge, Air Filter and Fittings
- 6 Meters PU Tube
- 1 Metre 2mm Silicone Rubber Tube
- 6 Meters 2mm Stainless Steel Sensor Tube
- 4 x Nozzle Brackets with Stainless Steel Ties
- Installation/Operation Manual
- 2 Meter Electrical Power/Interlock Cable



LM2050 SINGLE INJECTION NOZZLE PLASTIC LEAK ALARM


Kit Includes:

- LM2050 with 2-Line 16 Character LCD display with multiple languages and programmable operational settings
- ZR-20GF Air Pressure Regulator with Pressure Gauge, Air Filter and Fittings
- 3 Meters PU Tube
- 0.5 Metres 2mm Silicone Rubber Tube
- 3 Meters 2mm Stainless Steel Sensor Tube
- 2 x Nozzle Brackets with Stainless Steel Ties
- Installation/Operation Manual
- 2 Meter Electrical Power/Interlock Cable

NOZZLE AND BARREL PROTECTION + HOT RUNNER MOULD PROTECTION

'STANDARD' HOT-RUNNER LEAK DETECTION MANIFOLDS

'STANDARD' HOT-RUNNER Leak Detection Manifolds are used in addition with either an LA501, LA502 or LM2050 IMM Nozzle Leak Detector via a PCC-X Cable (not included).



NOZZLE AND BARREL PROTECTION + HOT RUNNER MOULD PROTECTION

4-ZONE 'STANDARD' HOT-RUNNER LEAK DETECTION MANIFOLDS



LA504-X 4-ZONE FIXED LEAK ALARM MANIFOLD

(requires connection to an LA501, LA502 or LM2050 IMM Nozzle Leak Detector Module via a PCC-X Cable). Kit Includes:

- LA504 Manifold (fixed type)
- 3 Meters PU Tube
- 1 Meter Xmm Silicone Rubber Tube. X=1.6 or 2.0.
- 5 Meters Xmm Stainless Steel Sensor Tube. X=1.6 or 2.0.
- (4)off Brackets, Spacers and Screws for Sensor Tube
- Installation/Operation Manual

PROGRAMMABLE OPTIONS VIA LA501, LA502 or LM2050. CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA504-M-H 4-ZONE MODULAR LEAK ALARM MANIFOLD

(requires connection to an LA501, LA502 or LM2050 IMM Nozzle Leak Detector Module via a PCC-X Cable. Requires an LA504-B-X base). Kit Includes:

- LA504 Modular Manifold with Handle Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

PROGRAMMABLE OPTIONS VIA LA501, LA502 or LM2050. CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA504-M-S 4-ZONE MODULAR LEAK ALARM MANIFOLD

(requires connection to an LA501, LA502 or LM2050 IMM Nozzle Leak Detector Module via a PCC-X Cable. Requires an LA504-B-X base). Kit Includes:

- LA504 Modular Manifold with Screw Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

PROGRAMMABLE OPTIONS VIA LA501, LA502 or LM2050. CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA504-B-X 4-ZONE MODULAR LEAK ALARM MANIFOLD BASE

Kit Includes:

- LA504-B Manifold Base
- 5 Meters Xmm Stainless Steel Sensor Tube. X=1.6 or 2.0.
- (4)off Brackets, Spacers and Screws for Sensor Tube
- 1 Meter Xmm Silicone Rubber Tube. X=1.6 or 2.0.

NOZZLE AND BARREL PROTECTION

+ HOT RUNNER MOULD PROTECTION

8-ZONE 'STANDARD' HOT-RUNNER LEAK DETECTION MANIFOLDS



LA508-X-N 8-ZONE FIXED LEAK ALARM MANIFOLD

(requires connection to an LA501, LA502 or LM2050 IMM Nozzle Leak Detector Module via a PCC-X Cable). Kit Includes:

- LA508 Manifold (fixed type)
- 3 Meters PU Tube
- 2 Meters Xmm Silicone Rubber Tube. X=1.6 or 2.0.
- 10 Meters Xmm Stainless Steel Sensor Tube. X=1.6 or 2.0.
- (8)off Brackets, Spacers and Screws for Sensor Tube
- Installation/Operation Manual

N =1 (ZONES 1-8), N =2 (ZONES 9-16), N =3 (ZONES 17-24), N =4 (ZONES 25-32). PROGRAMMABLE OPTIONS VIA LA501, LA502 or LM2050.



LA508-M-H-N 8-ZONE MODULAR LEAK ALARM MANIFOLD

(requires connection to an LA501, LA502 or LM2050 IMM Nozzle Leak Detector Module via a PCC-X Cable. Requires an LA508-B-X base). Kit Includes:

- LA508 Modular Manifold with Handle Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

N =1 (ZONES 1-8), N =2 (ZONES 9-16), N =3 (ZONES 17-24), N =4 (ZONES 25-32). PROGRAMMABLE OPTIONS VIA LA501, LA502 or LM2050'



LA508-M-S-N 8-ZONE MODULAR LEAK ALARM MANIFOLD

(requires connection to an LA501, LA502 or LM2050 IMM Nozzle Leak Detector Module via a PCC-X Cable. Requires an LA508-B-X base). Kit Includes:

- LA508 Modular Manifold with Screw Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

N =1 (ZONES 1-8), N =2 (ZONES 9-16), N =3 (ZONES 17-24), N =4 (ZONES 25-32). PROGRAMMABLE OPTIONS VIA LA501, LA502 or LM2050.



LA508-B-X 8-ZONE MODULAR LEAK ALARM MANIFOLD BASE

Kit Includes:

- LA508-B Manifold Base
- 10 Meters Xmm Stainless Steel Sensor Tube. X=1.6 or 2.0.
- (8)off Brackets, Spacers and Screws for Sensor Tube
- 2 Meters Xmm Silicone Rubber Tube. X=1.6 or 2.0

NOZZLE AND BARREL PROTECTION

+ HOT RUNNER MOULD PROTECTION

16-ZONE 'STANDARD' HOT-RUNNER LEAK DETECTION MANIFOLDS



LA516-M-H-N 16-ZONE MODULAR LEAK ALARM MANIFOLD


(requires connection to an LA501, LA502 or LM2050 IMM Nozzle Leak Detector Module via a PCC-X Cable. Requires an LA516-B-X base).

Kit Includes:

- LA516 Modular Manifold with Handle Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

N = 1 (ZONES 1-16), N = 2 (ZONES 17-32),

PROGRAMMABLE OPTIONS VIA LA501, LA502 or LM2050



LA516-M-S-N 16-ZONE MODULAR LEAK ALARM MANIFOLD


(requires connection to an LA501, LA502 or LM2050 IMM Nozzle Leak Detector Module via a PCC-X Cable. Requires an LA516-B-X base).

Kit Includes:

- LA516 Modular Manifold with Screw Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

N = 1 (ZONES 1-16), N = 2 (ZONES 17-32),

PROGRAMMABLE OPTIONS VIA LA501, LA502 or LM2050



LA516-B-X 16-ZONE MODULAR LEAK ALARM MANIFOLD BASE

Kit Includes:

- LA516-B Manifold Base
- 20 Meters Xmm Stainless Steel Sensor Tube
- (16)off Brackets, Spacers and Screws for Sensor Tube
- 4 Meters Xmm Silicone Rubber Tube

X=1.6 or 2.0

NOZZLE AND BARREL PROTECTION

+ HOT RUNNER MOULD PROTECTION

24-ZONE 'STANDARD' HOT-RUNNER LEAK DETECTION MANIFOLDS



LA524-M-H-N 24-ZONE MODULAR LEAK ALARM MANIFOLD (requires connection to an LA501, LA502 or LM2050 IMM Nozzle Leak Detector Module via a PCC-X Cable. Requires an LA524-B-X base).

Kit Includes:

- LA524 Modular Manifold with Handle Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

N = 1 (ZONES 1-24)

PROGRAMMABLE OPTIONS VIA LA501, LA502 or LM2050



LA524-M-S-N 24-ZONE MODULAR LEAK ALARM MANIFOLD (requires connection to an LA501, LA502 or LM2050 IMM Nozzle Leak Detector Module via a PCC-X Cable. Requires an LA524-B-X base).

Kit Includes:

- LA524 Modular Manifold with Screw Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

N = 1 (ZONES 1-24)

PROGRAMMABLE OPTIONS VIA LA501, LA502 or LM2050



LA524-B-X 24-ZONE MODULAR LEAK ALARM MANIFOLD BASE

Kit Includes:

- LA524-B Manifold Base
- 30 Meters Xmm Stainless Steel Sensor Tube
- (24)off Brackets, Spacers and Screws for Sensor Tube
- 6 Meters Xmm Silicone Rubber Tube

X=1.6 or 2.0




HOT RUNNER MOULD PROTECTION

'STAND-ALONE' HOT-RUNNER LEAK DETECTION MANIFOLDS

'STAND-ALONE' HOT-RUNNER Leak Detection Manifolds have an integral Control/Display/Relay Interlock Module.

They are connected directly to the IMM via a PCC-S-X cable (not included) and connected to the factory compressed air supply via an ZR-20GF Air Pressure Regulation System (not included).

NON-PROGRAMMABLE. CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



HOT RUNNER MOULD PROTECTION

4-ZONE 'STAND-ALONE' HOT-RUNNER LEAK DETECTION MANIFOLDS



LA504S-X 4-ZONE FIXED STAND-ALONE LEAK ALARM MANIFOLD.
Kit Includes:

- LA504S-X Manifold (fixed type)
- 3 Meters PU Tube
- 1 Meter Xmm Silicone Rubber Tube
- 5 Meters Xmm Stainless Steel Sensor Tube
- (4)off Brackets, Spacers and Screws for Sensor Tube
- Installation/Operation Manual

X=1.6 or 2.0. NON-PROGRAMMABLE. CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA504S-M-H 4-ZONE MODULAR STAND-ALONE LEAK ALARM MANIFOLD (requires an LA504-B-X base).

Kit Includes:

- LA504S Modular Manifold with Handle Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

NON-PROGRAMMABLE. CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA504S-M-S 4-ZONE MODULAR STAND-ALONE LEAK ALARM MANIFOLD (requires an LA524-B-X base).

Kit Includes:

- LA504S Modular Manifold with Screw Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

NON-PROGRAMMABLE. CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA504-B-X 4-ZONE MODULAR LEAK ALARM MANIFOLD BASE

Kit Includes:

- LA504-B Manifold Base
- 5 Meters Xmm Stainless Steel Sensor Tube
- (4)off Brackets, Spacers and Screws for Sensor Tube
- 1 Meter Xmm Silicone Rubber Tube

X=1.6 or 2.0



HOT RUNNER MOULD PROTECTION

8-ZONE 'STAND-ALONE' HOT-RUNNER LEAK DETECTION MANIFOLDS



LA508S-X 8-ZONE FIXED STAND-ALONE LEAK ALARM MANIFOLD

Kit Includes:

- LA508S-X Manifold (fixed type)
- 3 Meters PU Tube
- 2 Meters Xmm Silicone Rubber Tube
- 10 Meters Xmm Stainless Steel Sensor Tube
- (8)off Brackets, Spacers and Screws for Sensor Tube
- Installation/Operation Manual

X=1.6 or 2.0. NON-PROGRAMMABLE. CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA508S-M-H 8-ZONE MODULAR STAND-ALONE LEAK ALARM MANIFOLD (requires an LA508-B-X base).

Kit Includes:

- LA508S Modular Manifold with Handle Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

NON-PROGRAMMABLE. CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA508S-M-S 8-ZONE MODULAR STAND-ALONE LEAK ALARM MANIFOLD (requires an LA508-B-X base). Kit Includes:

- LA508S Modular Manifold with Screw Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

NON-PROGRAMMABLE

CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA508-B-X 8-ZONE MODULAR LEAK ALARM MANIFOLD BASE

Kit Includes:

- LA508-B Manifold Base
- 10 Meters Xmm Stainless Steel Sensor Tube
- (8)off Brackets, Spacers and Screws for Sensor Tube
- 2 Meters Xmm Silicone Rubber Tube

X=1.6 or 2.0



HOT RUNNER MOULD PROTECTION

16-ZONE 'STAND-ALONE' HOT-RUNNER LEAK DETECTION MANIFOLDS



LA516S-M-H 16-ZONE MODULAR STAND-ALONE LEAK ALARM MANIFOLD (requires an LA516-B-X base).

Kit Includes:

- LA516S Modular Manifold with Handle Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

NON-PROGRAMMABLE

CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA516S-M-S 16-ZONE MODULAR STAND-ALONE LEAK ALARM MANIFOLD (requires an LA516-B-X base).

Kit Includes:

- LA516S Modular Manifold with Screw Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

NON-PROGRAMMABLE

CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA516-B-X 16-ZONE MODULAR LEAK ALARM MANIFOLD BASE

Kit Includes:

- LA516-B Manifold Base
- 20 Meters Xmm Stainless Steel Sensor Tube
- (16)off Brackets, Spacers and Screws for Sensor Tube
- 4 Meters Xmm Silicone Rubber Tube

X=1.6 or 2.0



HOT RUNNER MOULD PROTECTION

24-ZONE 'STAND-ALONE' HOT-RUNNER LEAK DETECTION MANIFOLDS



LA524S-M-H 24-ZONE MODULAR STAND-ALONE LEAK ALARM MANIFOLD (requires an LA524-B-X base).

Kit Includes:

- LA524S Modular Manifold with Handle Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

NON-PROGRAMMABLE

CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA524S-M-S 24-ZONE MODULAR STAND-ALONE LEAK ALARM MANIFOLD (requires an LA524-B-X base).

Kit Includes:

- LA524S Modular Manifold with Screw Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

NON-PROGRAMMABLE

CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA524-B-X 24-ZONE MODULAR LEAK ALARM MANIFOLD BASE

Kit Includes:

- LA524-B Manifold Base
- 30 Meters Xmm Stainless Steel Sensor Tube
- (24)off Brackets, Spacers and Screws for Sensor Tube
- 6 Meters Xmm Silicone Rubber Tube

X=1.6 or 2.0





HOT RUNNER MOULD PROTECTION

'ULTIMATE' STAND-ALONE HOT-RUNNER LEAK DETECTION MANIFOLDS

ULTIMATE Multi-Zone Leak Detection Manifolds have both *POINT* and *LOOP* Leak Detection Zones and are available as 'Stand-Alone' units only and have an integral Control/Display/Relay Interlock Module.

They are connected directly to the IMM via a PCC-S-X cable (not included) and connected to the factory compressed air supply via an IR-1000GF Precision Air Pressure Regulation System (not included).

NON-PROGRAMMABLE. CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



HOT RUNNER MOULD PROTECTION

'ULTIMATE' 6-POINT + 1 LOOP LEAK DETECTION MANIFOLDS



LA506-1L-S-X 6-ZONE + 1 LOOP FIXED STAND-ALONE
ULTIMATE LEAK ALARM MANIFOLD. Kit Includes:

- LA506-1L-S **ULTIMATE** Manifold (fixed type)
- 3 Meters PU Tube
- 2 Meters Xmm Silicone Rubber Tube
- 10 Meters Xmm Stainless Steel Sensor Tube
- (24)off Brackets, Spacers and Screws for Sensor Tube
- Installation/Operation Manual

X=1.6 or 2.0 NON-PROGRAMMABLE. CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA506-1L-S-M-H 6-ZONE + 1 LOOP MODULAR STAND-ALONE
ULTIMATE LEAK ALARM MANIFOLD (requires an LA508-B-X-U base). Kit Includes:

- LA506-1L **ULTIMATE** Modular Manifold with Handle Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

NON-PROGRAMMABLE. CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA506-1L-S-M-S 6-ZONE + 1 LOOP MODULAR STAND-ALONE
ULTIMATE LEAK ALARM MANIFOLD (requires an LA508-B-X-U base). Kit Includes:

- LA506-1L **ULTIMATE** Modular Manifold with Screw Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

NON-PROGRAMMABLE. CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA508-B-X-U 8-ZONE ULTIMATE MODULAR LEAK ALARM
MANIFOLD BASE. Kit Includes:

- LA508-B Manifold Base
- 10 Meters Xmm Stainless Steel Sensor Tube
- (16)off Brackets, Spacers and Screws for Sensor Tube
- 2 Meters Xmm Silicone Rubber Tube

X=1.6 or 2.0



HOT RUNNER MOULD PROTECTION

'ULTIMATE' 12-POINT + 2 LOOP LEAK DETECTION MANIFOLDS




LA512-2L-S-M-H 12-ZONE + 2 LOOP MODULAR STAND-ALONE **ULTIMATE** LEAK ALARM MANIFOLD (requires an LA516-B-X-U base).

Kit Includes:

- LA512-2L **ULTIMATE** Modular Manifold with Handle Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

NON-PROGRAMMABLE

CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA512-2L-S-M-S 12-ZONE + 2 LOOP MODULAR STAND-ALONE **ULTIMATE** LEAK ALARM MANIFOLD (requires an LA516-B-X-U base).

Kit Includes:

- LA512-2L **ULTIMATE** Modular Manifold with Screw Release
- 3 Meters PU Tube
- Protection Base
- Installation/Operation Manual

NON-PROGRAMMABLE

CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA516-B-X-U 16-ZONE **ULTIMATE** MODULAR LEAK ALARM MANIFOLD BASE

Kit Includes:

- LA516-B Manifold Base
- 20 Meters Xmm Stainless Steel Sensor Tube
- (32)off Brackets, Spacers and Screws for Sensor Tube
- 4 Meters Xmm Silicone Rubber Tube

X=1.6 or 2.0



HOT RUNNER MOULD PROTECTION

'ULTIMATE' 20-POINT + 2 LOOP LEAK DETECTION MANIFOLDS



LA520-2L-S-M-H 20-ZONE + 2 LOOP MODULAR STAND-ALONE **ULTIMATE** LEAK ALARM MANIFOLD (requires an LA524-B-X-U base).

Kit Includes:

- LA520-2L **ULTIMATE** Modular Manifold with Handle Release
- 3 Meters PU Tube
- Protection Base
- AR-20GF Air Filter, Pressure Regulator, Gauge and Fittings
- Installation/Operation Manual

NON-PROGRAMMABLE. CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA520-2L-S-M-S 20-ZONE + 2 LOOP MODULAR STAND-ALONE **ULTIMATE** LEAK ALARM MANIFOLD (requires an LA524-B-X-U base).

Kit Includes:

- LA520-2L **ULTIMATE** Modular Manifold with Screw Release
- 3 Meters PU Tube
- Protection Base
- AR-20GF Air Filter, Pressure Regulator, Gauge and Fittings
- Installation/Operation Manual

NON-PROGRAMMABLE. CANNOT BE DAISY CHAINED AS PART OF A LARGER SYSTEM



LA524-B-X-U 24-ZONE ULTIMATE MODULAR LEAK ALARM MANIFOLD BASE

Kit Includes:



- LA524-B Manifold Base
- 30 Meters Xmm Stainless Steel Sensor Tube
- (48)off Brackets, Spacers and Screws for Sensor Tube
- 6 Meters Xmm Silicone Rubber Tube

X=1.6 or 2.0



HOT RUNNER MOULD PROTECTION

ACCESSORIES



B

B

LA-MAN-2-X 2-ZONE TUBE ADAPTOR MANIFOLD
 (Use to join Stainless Steel Tube to Stainless Steel Tube or PU Tube)

X=1 A=SS1.6mm B=SS1.6mm
 X=2 A=SS1.6mm B=SS2.0mm
 X=3 A=SS1.6mm B=PU4.0mm
 X=4 A=SS2.0mm B=SS2.0mm
 X=5 A=SS2.0mm B=PU4.0mm
 X=6 A=PU4.0mm B=PU4.0mm

LA-MAN-4-X 4-ZONE TUBE ADAPTOR MANIFOLD
 (Use to join Stainless Steel Tube to Stainless Steel Tube or PU Tube).

X=1 A=SS1.6mm B=SS1.6mm
 X=2 A=SS1.6mm B=SS2.0mm
 X=3 A=SS1.6mm B=PU4.0mm
 X=4 A=SS2.0mm B=SS2.0mm
 X=5 A=SS2.0mm B=PU4.0mm
 X=6 A=PU4.0mm B=PU4.0mm

TUBE-SS-10M-X 10 METER COIL OF Xmm OD
 STAINLESS STEEL TUBING

Use as Sensor Tubing within Hot Runner Mould or
 Moulding Machine Barrel/Nozzle

X = 1.6 for 1.6mm Sensor Tubing


X = 2.0 for 2mm Sensor Tubing

TUBE-PU-10M 10 METER COIL OF 4mm PU (plastic)
 TUBING

Use for Compressed/Regulated Air Supply



ACCESSORIES

**TUBE-SIL-10M-X** 10 METER COIL OF HEAT STABILISED SILICONE RUBBER TUBING

Use to make Sensor Tube ends for LA500, LM2050 and to extend range of Multi-Zone Manifold Zones.

X = 1.6 or 2.0 ID (to suit OD of stainless tube)

**NUT-SS-X** NUT and OLIVE SET (5pcs) FOR Xmm OD STAINLESS STEEL TUBING

Use to connect Stainless Steel Sensor Tube to Manifold (LA508, LA508-B or LA516-B)

X = 1.6 or 2.0 ID (to suit OD of stainless tube)

**FIT-SS-SS-X** JOINER FITTING FOR Xmm OD STAINLESS STEEL TUBING

Use to connect Stainless Steel Sensor Tube to Stainless Steel Sensor Tubing

X = 1.6 or 2.0 ID (to suit OD of stainless tube)

**FIT-PU-SS-X** JOINER FITTING FOR 4mm PU TUBE TO Xmm OD STAINLESS STEEL TUBING


Use to connect PU Tube to Stainless Steel Sensor Tubing

X = 1.6 or 2.0 ID (to suit OD of stainless tube)

**BKT-SS** FIXING BRACKET SET (10pcs) FOR STAINLESS STEEL TUBING


Use to secure Stainless Steel Sensor Tube to Hot Runner Manifold/Mould Plate etc. Kit Includes:

- 10 x Fixing Brackets
- 10 x M2.5mm Stainless Screws
- 10 X Offset Spacers

**NOZ-BKT** FIXING BRACKET SET (10pcs) FOR STAINLESS STEEL SENSOR TUBE

Use to secure Stainless Steel Sensor Tube at the Injection Moulding Machine Nozzle Kit Includes:

- 10 x Fixing Brackets
- 10 x 300mm Stainless Steel ties





ACCESSORIES



PCC-X POWER/COMUNICATION CABLE X Meter

Use to connect LA500 or LM2050 to Manifold or Manifold to Manifold (daisy chain) up to 32-Channels.

Standard sizes are (Meters):

X = 0.6, X = 1.5, X = 3, X = 5, X = 10



PCC-S-X POWER/RELAY INTERLOCK CABLE X Meter

Use to connect STAND-ALONE Manifolds to DC Power and Interlock Relay connections

Standard sizes are (Meters):

X = 3, X = 5, X = 10



ZR-20GF AIR PRESSURE REGULATOR WITH PRESSURE GAUGE, AIR FILTER AND FITTINGS

Use for LA500 and LM2050 and LA504S/LA508S/LA516S/LA524S Manifold Systems



IR-1000GF PRECISION AIR PRESSURE REGULATOR WITH PRESSURE GAUGE, AIR FILTER AND FITTINGS

Use for LA506-1I-S / LA512-2L-S AND LA520-2L-S **ULTIMATE** Manifold Systems



AR-G-5 AIRTECT 0.6 BAR PRESSURE GAUGE

Set of (5)



‘FOCUS ON PREVENTION’

DESIGNED AND MANUFACTURED BY

GLOOMDITCH SWORDS ENTERPRISE PART OF GLOREX
100-102 GLOOMDITCH ROAD, LONDON E1 1RR, ENGLAND.
WWW.AIRTECT.COM